




FENEK




Mouse Button Function Definition




LED setting

RGB special display effect setting



Advanced settings



【User-defined DPI value】

Customize the DPI values of the mouse

【Mouse double -click speed】

Double-click speed adjustment (the greater ,the numerical value, the higher ,the speed)

【Mouse scroll speed】

Wheel rolling speed adjustment (the greater the numerical value, the higher the speed)

【Report rate setting】

User defined requency of communication between mouse and computer

■ Connection to computer_____

- 1.Insert the USB connector of mouse into the available USB interface of computer
- 2.The operating system automatically identifies the mouse and installs all the necessary drivers
- 3.Where the computer system fails to identify the mouse, please insert the mouse connector into another available USB interface at the back of computer chassis and restart your computer.


■ Installation of driver software_____

- 1.Please uninstall all other mouse software in the system before installing the accompanying software for mouse.
- 2.Put the supplementary CD supplied with the product in your CD/DVD driver
- 3.When the CD is properly placed in the CD driver, the mouse driver setup program will run automatically
- 4.If the system prevents the driver automatically running for security reasons, please open the CD/DVD driver folder (for example, F:\)
- 5.Start the [setup.exe], and perform the operation in the light of setup wizard
- 6.Upon the completion of installation, the system toolbar will permanently display the "mouse driver" icon.

Mouse setup procedure - main interface



【Button setting】



Macrosetting

The screenshot shows a software window titled "Macrosetting" with a standard Windows-style title bar (minimize, maximize, close buttons). The interface is divided into several sections:

- Profile Selection:** A vertical list on the left shows "Default Profile" (selected), "Profile1", "Profile2", and "Profile3". Below this are "+ New" and "- Delete" buttons.
- Information Section:** Below the profile list, there is a "Relation program" field with a text box and a "Remark" field with a text box.
- Macro list:** A large vertical list box in the center-left. Below it are "New" and "Delete" buttons.
- Key list:** A large vertical list box in the center-right. Below it are "Modify" and "Delete" buttons.
- Advanced setting:** A section on the right containing:
 - A "Start record" radio button (selected).
 - Four checkboxes: "Automatic recording time delay", "Cycle until the key released", "Cycle until any key pressed", and "Specified cycle times".
 - A text input field below the checkboxes.
 - An "Insert event" dropdown menu.
- Navigation Tabs:** At the top, there are four tabs: "Key binding", "Macro" (active), "Advanced setting", and "LED setting".
- Footer:** The bottom of the window displays "Driver version: 1.3" on the left and "OK", "Apply", and "Cancel" buttons on the right.